

# Brakes

---

## Parking Brake Lever Freeplay


Refer to *Safety Precautions* on page 77.

### Inspection

1. Pull the parking brake lever.
2. Measure the distance the parking brake starts to take hold.

Parking brake lever freeplay is:

2 9/16-3 3/8 in (65-85 mm)



If adjustment is necessary, have the parking brake adjusted by your Honda dealer.