

# Indicators & Displays

---

(U, CM type only)

## Display Check

When the ignition switch is turned ON ( I ), the multi-function display will temporarily show all the modes and digital segments so you can make sure the liquid crystal display is functioning properly.

If any part of these displays does not come on when it should, have your dealer check for problems.

