

Fuses..... 38, 89

G

Gasohol 100

Gear Range 16

H

Headlight Aim 70

Headlight Dimmer Switch 18

Helmet Holder 28

High Beam Indicator 17

Horn Button 18

I

Ignition key 92

Ignition Switch 19, 21

Indicators 17

Instruments 16

L

Load Limits 11

Loading Guidelines..... 11

M

Maintenance

Fundamentals..... 35

Importance 31

Safety 31

Schedule..... 32

Maximum Weight Limit..... 11, 102

Modifications 10

N

Neutral Indicator 17

O

Odometer 16

Oil

Engine 39, 51

P

Parking 8

Parts Location 14

Petrol 26, 100

PGM-FI (Programmed Fuel Injection)

Malfunction Indicator Lamp (MIL) 17, 74