

The average fuel mileage and fuel consumption will be based on tripmeter A.

- **Current fuel mileage:**
Current instant fuel mileage. If your speed is less than 3 mph (5 km/h), "---.-" is displayed. When "---.-" is displayed at speeds above 3 mph (5 km/h), go to your dealer for service.
 - **Average fuel mileage:**
Average fuel mileage since tripmeter A was reset.
"---.-" is displayed after resetting tripmeter A.
When "---.-" is displayed in other cases, go to your dealer for service.
 - **Fuel consumption:**
Total fuel consumption since tripmeter A was reset.
"---.-" is displayed after resetting tripmeter A.
When "---.-" is displayed in other cases, go to your dealer for service.
- ▶ **To reset the average fuel mileage and fuel consumption:** ➡ P.24