


Helmet Holder

The helmet holder is located under the front seat.

A helmet set wire is in the tool kit.



► Use the helmet holder only when parked.

Removing the front seat ➔ P.79

⚠WARNING

Riding with a helmet attached to the holder can interfere with the rear wheel or suspension and could cause a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.