


Front Lower Cover



Removal

1. Remove the right and left side panels.
► P. 80
2. Remove the clips. ► P. 77
3. Remove the bolts.
4. Remove the front lower cover.

Installation

Install the parts in the reverse order of removal.