

Engine

Number.....	139
Oil.....	67, 86
Oil Filter.....	88
Overheats.....	108
Starting.....	38
Stop Switch.....	34, 130
Stopping.....	130
Will Not Start.....	107

Environment	137
--------------------------	-----

Equipment

Owner's Manual.....	48
---------------------	----

F

Flooded Engine	38
-----------------------------	----

Front Utility Box	50, 51
--------------------------------	--------

Fuel

Fuel Gauge.....	21
Recommended.....	46
Tank Capacity.....	46

Fuses	66, 126
--------------------	---------

G

Gasohol	145
----------------------	-----

Gasoline	46
-----------------------	----

H

Hazard Switch	34
----------------------------	----

Headlight Aim	104
----------------------------	-----

Headlight Dimmer Switch	34
--------------------------------------	----

Helmet Holder	49
----------------------------	----

High Beam Indicator	33
----------------------------------	----

High Coolant Temperature Indicator	33, 108
---	---------

Honda Contacts	148
-----------------------------	-----

Horn Button	34
--------------------------	----

I**Ignition Cut-off System**

Banking Sensor.....	130
---------------------	-----

Side Stand.....	97
-----------------	----

Ignition Key	129
---------------------------	-----

Ignition Switch	35, 130
------------------------------	---------

Indicators	32
-------------------------	----

Information Record	154
---------------------------------	-----

Instruments	20
--------------------------	----

Instruments, Controls, & Other

Features.....	130
---------------	-----