

## **| Odometer**

Total distance ridden.

When "-----" is displayed, go to your dealer for service.

## **| Tripmeter A/B**

Distance ridden since the tripmeter was reset.

When "----.-" is displayed, go to your dealer for service.

▶ **To reset the tripmeter:** ➡ **P.28**

## **| Current fuel mileage**

The current fuel mileage shows the current fuel mileage you are getting.

When your speed is less than 3 mph (5 km/h): "----.-" is displayed.

When "----.-" is displayed except for the above-mentioned cases, go to your dealer for service.