Instruments (Continued)

Order of priority for the color:



Base color mode

The display switches as follows by pressing and holding the SEL button:



When the mode you want to set is appears, release the SEL button.