

Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ➔ P. 76

Tires and wheels	Check the air pressure (➔ P. 89), examine tread for wear and damage (➔ P. 89), and check the wheels for damage.
Fluid levels	Check the engine oil level (➔ P. 102), engine coolant level (➔ P. 108), and brake fluid level (➔ P. 110).
Lights	Check that the headlight, position lights, brake light, taillight, license plate light and turn signals are working properly.
Controls	Check the freeplay of the clutch lever (NC700X NC750XA) (➔ P. 119) and throttle grip (➔ P. 122), Check the front brake lever (➔ P. 126), rear brake pedal and parking brake (NC700XD NC750XD) (➔ P. 112) operate properly.
Drive chain	Check the slack (➔ P. 115), adjust the slack (➔ P. 116), and lubricate (➔ P. 87) as needed.
Fuses	Check that you have a full supply of spare fuses.
Nuts & bolts	Check the major nuts and bolts, and tighten as needed.