


Lower Cowl

NC700X NC750XA



Removal

1. Remove the screws.
2. Remove the lower cowl by releasing its prongs from the grommets.

Installation

Install the parts in the reverse order of removal.