


To reset the tripmeter, average fuel mileage and fuel consumption

!a To reset the tripmeter A, average fuel mileage, and fuel consumption together, press and hold the B button.



!b When they are reset, reset display appears at each indication.



!c Then, the display returns to the last selected indication.



!d To reset the tripmeter B, press and hold the B button with the tripmeter B displayed.

