

Instruments *(Continued)*

Odometer

Total distance ridden.

When "-----" is displayed, go to your dealer for service.

Tripmeter A/B

Distance ridden since the tripmeter was reset.

When "----.-" is displayed, go to your dealer for service.

▶ **To reset the tripmeter:** ➡ P.29

Current fuel mileage

The current fuel mileage shows the current fuel mileage you are getting.

When your speed is less than 3 mph (5 km/h): "---.-" is displayed.

When "---.-" is displayed except for the above-mentioned cases, go to your dealer for service.

Average fuel mileage A/B

Shows each average fuel mileage in conjunction with each tripmeter.

When each tripmeter is reset, each average fuel mileage will also reset.

▶ **To reset the tripmeter:** ➡ P.29

When each tripmeter is reset: "---.-" is displayed.

When "---.-" is displayed except for the above-mentioned cases, go to your dealer for service.