

## Instruments (Continued)

### Tachometer color information

Depending on the selected mode, the information of the riding conditions shows by changing the tachometer segment color.



The tachometer color information modes:

#### Base color mode

- User setting mode
- Gear position mode
- DCT mode
- Engine rev mode

**NC750XD**

#### ECO mode

#### Shift up mode

When the user setting mode or DCT mode (**NC750XD**) in the base color mode is set, the ECO mode and/or shift up mode can be used at the same time.

Order of priority for the color:

**Shift up mode**

>

**ECO mode**

>

#### Base color mode

- User setting mode
- DCT mode **NC750XD**