


2 Clock setting:

- 1 Press the SEL button until the desired hour is displayed.
 - ▶ When the 12HOUR display is set, the AM/PM is displayed. The display changes from 11 to 12, it will switch at the same time.
 - ▶ Press and hold the SEL button to advance the hour fast.



- 2 Press the SET button. The minute digits start flashing.



- 3 Press the SEL button until the desired minute is displayed.
 - ▶ Press and hold the SEL button to advance the minute fast.



- 4 Press the SET button. The clock is set, and the display moves to the backlight brightness H (high) adjustment.