

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.  
Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 76	<b>Drive Chain</b> .....	P. 117
<b>Maintenance Schedule</b> .....	P. 78	<b>Clutch</b> .....	P. 121
<b>Maintenance Record</b> .....	P. 81	<b>Throttle</b> .....	P. 124
<b>Maintenance Fundamentals</b> .....	P. 82	<b>Crankcase Breather</b> .....	P. 126
<b>Removing &amp; Installing Body Components</b> ..	P. 97	<b>Other Adjustments</b> .....	P. 127
Battery .....	P. 97	Adjusting the Headlight Aim.....	P. 127
Clip .....	P. 98	Adjusting the Brake Lever .....	P. 128
Lower Cowl .....	P. 99		
Maintenance Lid .....	P. 101		
<b>Spark Plug</b> .....	P. 102		
<b>Engine Oil</b> .....	P. 105		
<b>Coolant</b> .....	P. 111		
<b>Brakes</b> .....	P. 113		
<b>Side Stand</b> .....	P. 116		