

## Periodic Checks

You should also perform other periodic maintenance checks at least once a month regardless of how often you ride, or more often if you ride frequently.

Also, check the odometer reading against the Maintenance Schedule and perform all maintenance that is due. ➤ P. 78

|                  |   |
|------------------|---|
| Tires and wheels | Check the air pressure (➤ P. 92), examine tread for wear and damage (➤ P. 92), and check the wheels for damage.   |
| Fluid levels     | Check the engine oil level (➤ P. 105), engine coolant level (➤ P. 111), and brake fluid level (➤ P. 113).   |
| Lights           | Check that the headlight, position lights, brake light, taillight, license plate light and turn signals are working properly.   |
| Controls         | Check the freeplay of the clutch lever ( <b>NC750X/XA</b> ) (➤ P. 121 ) and throttle grip (➤ P. 124), Check the front brake lever (➤ P. 128), rear brake pedal and parking brake ( <b>NC750XD</b> ) (➤ P. 115 ) operate properly. |
| Drive chain      | Check the slack (➤ P. 117), adjust the slack (➤ P. 118), and lubricate (➤ P. 90) as needed.   |
| Fuses            | Check that you have a full supply of spare fuses.   |
| Nuts & bolts     | Check the major nuts and bolts, and tighten as needed.  |