


# Basic Operation Flow

## Pre-ride Inspection P.48

Carefully inspect your scooter to make sure that it is safe to ride.



## Acceleration P.33

Apply throttle gradually.  
Obey the speed limit.



## Starting the Engine P.30

Start and warm the engine.  
Avoid revving the engine.

How to use basic features.

- Instruments  P.20
- Switches  P.26
- Steering Lock  P.27
- Shutter  P.28



## Starting the Scooter P.33

Before pulling away, indicate your direction with the turn signal switch, and check for oncoming traffic.

