


## Storage Equipment *(Continued)*

### Helmet Holder

The helmet holder is located under the seat.

- ▶ Use the helmet holder only when parked.



### Center Compartment

Never exceed the maximum weight limit.

#### Maximum Weight: 22 lb (10 kg)

- ▶ Do not store any items that are flammable or susceptible to heat damage.
- ▶ Do not store valuables or fragile articles.

Opening the seat. ➔ P.37

## **! WARNING**

Riding with a helmet attached to the holder can interfere with your ability to safely operate the scooter and could lead to a crash in which you can be seriously hurt or killed.

Use the helmet holder only while parked. Do not ride with a helmet secured by the holder.