

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.

Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 43	<b>Coolant</b> .....	P. 73
<b>Maintenance Schedule</b> .....	P. 45	<b>Brakes</b> .....	P. 75
<b>Maintenance Fundamentals</b> .....	P. 48	<b>Throttle</b> .....	P. 80
<b>Removing &amp; Installing Body Components</b> ...	P. 61	<b>Crankcase Breather</b> .....	P. 81
Battery .....	P. 61	<b>Other Adjustments</b> .....	P. 82
Battery Lid .....	P. 62	Headlight Aim .....	P. 82
Center Cover .....	P. 63		
Clip .....	P. 64		
Fuse Box Maintenance Cover .....	P. 65		
<b>Spark Plug</b> .....	P. 66		
<b>Engine Oil</b> .....	P. 68		
<b>Air Cleaner</b> .....	P. 72		