

Unstable Engine Running Occurs Sporadically

If the fuel pump filter is clogged, unstable engine running will occur sporadically while riding.

Even if this symptom is occurred, you can continue to ride your scooter.

If unstable engine running is occurred even sufficient fuel is available, have your scooter inspected by your dealer as soon as possible.