

<b>F</b>	
Fairing Pocket.....	40
Flooded Engine .....	32
Fuel	
Gauge .....	20, 21
Recommended .....	35
Tank Capacity.....	35
Fuses.....	53, 94
<b>G</b>	
Gasohol .....	111
Gasoline .....	35
<b>H</b>	
Headlight Aim .....	82
Headlight Dimmer Switch.....	26
Helmet Holder .....	38
High Beam Indicator .....	24
High Coolant Temperature	
Indicator .....	24, 85
Honda Contacts.....	115
Hook.....	41
Horn Button.....	26
<b>I</b>	
Ignition Key.....	97
Ignition Switch.....	27
Indicators.....	24
Information Record .....	120
Inner Rack .....	41
Instruments .....	20
<b>L</b>	
Labels.....	7
Load Limits.....	14
Loading Guidelines.....	14
<b>M</b>	
Maintenance	
Fundamentals .....	48
Importance .....	43
Safety .....	44
Schedule.....	45
Maximum Weight Limit .....	14
Modifications .....	13