


Driver Controls


Drive Mode Select Lever (SXS1000M3L/M5L)

The drive mode select lever, located to the right of the shift select lever, has three drive mode positions: Turf, 2WD and *I* - 4WD (page 106).

drive mode select lever



drive mode positions



To check your present drive mode, look at the drive mode indicator.

drive mode select lever position	Turf	2WD	<i>I</i> - 4WD
drive mode indicator	