

Instruments & Controls

The items listed below are described in this section.

Operation Component Locations	13
Indicators & Displays.....	16
Neutral Indicator.....	18
Reverse Indicator	18
Electric Power Steering (EPS) Indicator.....	18
High Coolant Temperature Indicator.....	18
PGM-FI Malfunction Indicator Lamp (MIL)	18
Seat Belt Indicator.....	18
Low Oil Pressure Indicator.....	19
Hill Start Assist (HSA) Indicator.....	19
I - 4WD Indicator.....	19
Clutch Temperature Indicator	19
Multi-function Display.....	22
Speedometer.....	23
Tachometer	24
Fuel Gauge.....	25
Odometer Display.....	26
Maintenance Minder Indicator	31
Digital Clock.....	32
Gear Position Indicator.....	33
AT Indicator / MT Indicator / LOW Indicator	34
SPORT Indicator.....	34
Drive Mode Indicator	35
Driver Controls	36
Ignition Switch.....	36
Headlight Switch	37
Shift Select Lever	38
Drive Mode Select Switch	39
AT/MT Switch.....	41
SPORT Switch	42
Hill Start Assist (HSA) Switch	43

(cont'd)