

Indicators & Displays

Multi-function display	This display includes the following functions.
Speedometer	Shows driving speed in miles or kilometers per hour (page 23).
Tachometer	Shows the engine rpm (page 24).
Fuel gauge	Shows approximate fuel supply available (page 25).
Odometer display	Shows the odometer, tripmeter, coolant temperature gauge, hour meter, maintenance tripmeter and maintenance hour meter (page 26).
Maintenance minder indicator	Shows when specified maintenance interval is reached (page 31).
Digital clock	Shows the time (hours and minutes) (page 32).
Gear position indicator	Shows the gear position (page 33).
AT/MT/LOW indicator	Shows the transmission mode (page 34).
SPORT indicator	
Drive mode indicator	Shows the driving mode (page 35).
SEL/SET switch	This switch is used to select the mode, to change the mileage unit and adjust/ resets the digital clock, tripmeter and hour meter (page 22).