


Indicators & Displays

Fuel Gauge


The fuel gauge shows the approximate fuel supply available. The fuel tank capacity is:

7.27 US gal (27.5 ℓ)



When the last segment blinks, you should refill the tank as soon as possible. The amount of fuel remaining when the blinking starts is approximately:

1.14 US gal (4.3 ℓ)



Fuel gauge failure:

If the fuel system has an error, the fuel gauge indicators will be displayed as shown in the illustrations.

If this occurs, see your dealer as soon as possible.

