

Fuel Capacity


Fuel tank capacity:
7.27 US gal (27.5 ℓ)

When there is only one segment left in the fuel gauge (page 25), fuel will be low and you should refuel as soon as possible.

Refueling Procedure

Refer to *Safety Precautions* on page 107.

RIGHT SIDE



1. Open the right side door (page 48).
2. Turn the fuel fill cap counterclockwise.

(cont'd)