Oil Recommendation

API classification	GL-5 except oils labeled as energy conserving on the circular API service label
type	hypoid gear oil
viscosity (weight)	SAE 80W-90
suggested oil	Honda shaft drive oil or equivalent

Checking Oil

Refer to Safety Precautions on page 107.

- 1. Park your Honda SXS on a firm, level surface. Shift the shift select lever into the park (P) position.
- 2. Remove the oil check bolt and sealing washer.
- 3. Make sure the oil level is at the lower edge of the oil check inspection hole.
- 4. Install the oil check bolt with a new sealing washer and tighten to the specified torque:

9 lbf·ft (12 N·m, 1.2 kgf·m)

RIGHT REAR sealing washer lower edge of oil check inspection hole oil check bolt