Brake Pedal Inspection

Refer to Safety Precautions on page 107.

Check that the brake pedal moves smoothly and does not feel abnormally spongy according to the maintenance schedule (page 112).

