

# Indicators & Displays

---



## **FLV Warning Indicator (SXS1000S4D only)**

This indicator comes on briefly when the ignition switch is turned ON (q).

This indicator comes on and stays on when there is a problem with your vehicle's FOX® Live Valve (FLV) system. If this happens, reduce speed and take your vehicle to a dealer as soon as possible.



## **FLV SPORT Indicator (SXS1000S4D only)**

This indicator comes on briefly when the ignition switch is turned ON (q).

This indicator comes on when FLV is in the SPORT mode (page 181).



## **FLV NORMAL Indicator (SXS1000S4D only)**

This indicator comes on briefly when the ignition switch is turned ON (q).

This indicator comes on when FLV is in the NORMAL mode (page 181).



## **LAUNCH MODE Indicator (SXS1000S4D only)**

This indicator comes on briefly when the ignition switch is turned ON (q).

This indicator comes on when launch mode is activated (page 96). If this indicator flashes, launch mode is deactivated. Release the accelerator pedal and shift paddles and wait until the indicator goes off. Verify the preconditions are met and reactivate launch mode. (page 96).



## **High Beam Indicator (SXS1000S4D only)**

This indicator comes on when the high beams are on (page 39).