

Is Your Vehicle Ready to Drive?

Tie-rod Ends The wheels need to be lifted off the ground to correctly check the tie-rod ends, so it cannot be done in the pre-drive inspection. To have the tie-rod ends properly inspected, see your dealer.

Cargo Be sure items in the cargo bed are within the cargo limit and are properly secured to prevent shifting (pages 82, 83).

Seat Position Make sure the driver seat is secured in the proper seat position. If necessary, adjust the seat position (page 57).

Seat Belts Make sure all seat belts are in good condition and operate properly. The seat belts must move smoothly when pulled out, and retract on their own when released. The latch plates should click securely into the buckles and release when the release buttons are pushed firmly.

Side Nets Make sure all side nets and their mounting hardware are in good condition and that they latch and tighten securely.