


Maintenance Component Locations

front suspension spring
pre-load adjusters
(page 151)

brake light switch
(page 160)

brake fluid
reservoir tank
(page 155)

driveshaft boots
(page 169)



front brake calipers
(page 157)