The tool kit and the gear change tool are stored in the compartment under the seat bottom.

To access the tool kit and the gear change tool, remove the seat bottom (page 106).

An optional, larger tool kit may be available. Check with your dealer's parts department.

## UNDER SEAT BOTTOM LEFT SIDE

