


# Lubrication

---

Lubricate the parking brake pivot as shown in the following illustration.

Remove the dust cover.



parking brake pivot

Lubricate the drive mode select lever pivot as shown in the following illustration.

Remove the front hood (page 105).

## UNDER FRONT HOOD



drive mode select lever pivot