

Quick Reference

Scheduled Maintenance	Initial: 100 miles (150 km) Regular: every 600 miles (1,000 km)
Pre-drive Inspection	Each time before you drive (page 58): tires, fuel level, oil level, underbody, air cleaner housing drain tube, coolant, brake fluid, driveshafts, suspension, exhaust system, wheels, lights, controls, seat belts.
Fuel/Capacity	Unleaded gasoline, pump octane number 86 or higher 4.07 US gal (15.4 ℓ)
Engine Oil/ Capacity	API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil (USA & Canada) or Honda 4-stroke oil, or an equivalent after disassembly: 3.5 US qt (3.3 ℓ) after draining: 3.1 US qt (2.9 ℓ) after draining & oil filter change: 3.2 US qt (3.0 ℓ)
Maximum Weight Capacity	880 lb (399 kg) operator, passenger, all cargo and accessories