

# Engine Oil & Filter

---

## Changing Engine Oil & Filter

Refer to *Safety Precautions* on page 105.

Your Honda SXS's oil filter has very specific performance requirements. Use a new Honda Genuine oil filter specified for your model or a filter of equal quality.

### NOTICE

*Using the wrong oil filter may result in leaks or engine damage.*

This procedure requires mechanical skill and professional tools such as a torque wrench, and access from underneath the vehicle, as well as the means for disposing of the drained fluid (page 202). If you do not have the skills or the tools, see your dealer.

#### *Drain the Engine Oil:*

1. Make sure the Honda SXS is parked on level ground. Set the parking brake, and jack up and support your Honda SXS (page 123).
2. Remove the front seat (page 122) and left side rubber dust cover.
3. Remove the oil fill cap.

UNDER SEAT  
LEFT SIDE

rubber  
dust  
cover

oil fill cap

