Riding in Reverse

NOTICE

Your ATV may be equipped with a reverse speed limiter, which helps the vehicle to maintain a safe speed while riding in reverse gear.

- 6. Release the rear brake lever/parking brake lever.
- 7. Open the throttle gradually and ride slowly. Do not open the throttle suddenly or make abrupt turns.
- 8. To stop, close the throttle and gradually apply both the front and rear brakes. Do not abruptly apply the rear brake alone.
- 9. To shift out of reverse and into neutral, press the upshift switch (5) once to shift into "N" (neutral) gear (the neutral indicator is on.).

The transmission cannot be shifted from neutral back into reverse when the engine speed is above 3,000 rpm or speed of your ATV is above 2 mph (3 km/h).

3 WARNING

Applying only the rear brake abruptly when operating in reverse gear could cause the front wheels to lift off the ground and the ATV could overturn backwards.

Carefully apply both the front and rear brakes when stopping in reverse gear.