
Starting & Stopping the Engine

- 3. Warm up the engine by opening and closing the throttle slightly.
- 4. About 5 seconds after the engine starts, push the choke knob down all the way to fully OFF (B).
- 5. If idling is unstable, open the throttle slightly.

High Air Temperature 35°C (95°F) or above

LEFT HANDLEBAR



(1) start button

(1)

- 1. Do not use the choke.
- 2. With the throttle slightly open, press the start button (1).