

# Index

## T

throttle	
lever.....	22, 109
tires,	
air pressure .....	135
flat .....	170
replacing.....	140
repairing .....	139
specifications.....	140
thread conditions .....	138
tool kit .....	90
trailer towing,	
operational guidelines .....	40
weight limits.....	39
training, rider.....	32
transporting your ATV .....	154
trouble, unexpected .....	161
troubleshooting, starting.....	164
turning,	
on hills or slopes.....	71
on level ground.....	64

## V

valve, fuel.....	16
valve clearance .....	118
vehicle identification no. (VIN) .....	182