


Vehicle Identification

Color Label & Code

The color label (1) is attached to the frame below the seat. Remove the seat ([page 88](#)) to check the label.

The color code is helpful when ordering replacement parts. You may record the color and code in the Quick Reference section at the rear of this manual.

UNDER SEAT



(1) color label