

# Storing Your Honda

---

4. Drain the carburetor into an approved gasoline container and dispose of it in an approved manner (page 156).

If storage will last longer than one month, carburetor draining is important to assure proper performance after storage.

## **3 WARNING**

Gasoline is highly flammable and explosive. You can be burned or seriously injured when handling fuel.

- Stop the engine and keep heat, sparks and flame away.
- Handle fuel only outdoors.
- Wipe up spills immediately.

5. To prevent rusting in the cylinder, perform the following:

- Remove the spark plug cap from the spark plug.
- Remove the spark plug.  
Do not connect the spark plug to the spark plug cap.
- Pour a tablespoon (15 – 20 cc) of clean engine oil into the cylinder and cover the spark plug hole with a piece of cloth.
- With the engine stop switch in the OFF (r ) position, press the start button several times to crank the engine and distribute the oil.
- Reinstall the spark plug and spark plug cap.

(cont'd)