

# Index

---

stalling on a hill .....	95
start button .....	36
starting,	
engine .....	74
troubleshooting .....	208
stop switch, engine .....	36
stopping engine .....	79
storage,	
ATV .....	200
owner's manual .....	119
suspension,	
adjustment .....	161
spring pre-load .....	162
switch,	
downshift .....	40, 83
drive mode select .....	39
engine stop .....	36
headlight .....	37
headlight dimmer .....	37
ignition .....	34
reverse .....	43
upshift .....	40, 83

## T

throttle,	
cable .....	154, 155
lever .....	38, 154, 155
tires,	
air pressure .....	176
flat .....	216
repairing .....	180
replacing .....	181
thread conditions .....	178, 179