

Instruments & Controls

This section shows the location of all indicators and controls you would normally use before or while riding your ATV.

The items listed on this page are described in this section. Instructions for other components are presented in other sections of this manual where they will be most useful.

Operation Component Locations	11
Indicators & Displays	14
Multi-function Display.....	20
Speed and Mileage Unit Changing.....	23
4WD Indicator	23
Gear Position Indicator.....	24
Fuel Gauge	25
Digital Clock	27
Odometer.....	28
Tripmeter.....	28
Coolant Temperature Gauge	29
Hour meter.....	31
Maintenance Tripmeter & Maintenance Hour meter.....	32

(cont'd)