

B

bank angle sensor ignition cut-off system.....	65
battery.....	164
brake light switch adjustment.....	150
brakes,	
cables.....	149
fluid.....	143
front brake lever.....	33
pad wear.....	146
parking.....	34
rear brake lever.....	33
rear brake lever freeplay.....	148
rear brake pedal.....	33
braking.....	76
break-in guidelines.....	217
button, hourmeter/odometer/tripmeter select.....	14, 17, 20, 21, 22