

Index

I

identification, vehicle	226
ignition switch	34
indicators,	
4WD indicator	14, 18, 23
fuel warning indicator	14, 17
gear position indicator	24
high coolant temperature indicator	14, 17, 213
maintenance minder indicator	32
neutral indicator	14, 17
PGM-FI indicator	17
PS (Electric Power Steering) indicator (TRX420FM2 only)	17
reverse indicator	17
inspection, pre-ride	55

K

key,	
lost	221
number	221
kit, tool	112

L

labels, safety	5
lamp check	15
lever,	
2WD/4WD	35
limit, weight	60
load limits	60
loading guidelines	61
lubrication,	
engine oil	122
front final gear oil	134
rear final gear oil	131