

Basic Operation & Riding

This section gives basic riding instructions, including how to start and stop your engine, how to use the throttle and brakes, and what to do when you're through riding.

To protect your new engine and enjoy optimum performance and service life, refer to Break-in Guidelines ([page 201](#)).

For information about carburetor adjustment for riding at high altitude, see [page 202](#).

Safe Riding Precautions	40
Off-road Use Only	40
Keep Hands and Feet on Controls	41
Control Speed	42
Use Care on Unfamiliar or Rough Terrain	43
Do Not Perform Stunts	44
Starting & Stopping the Engine	45
Preparation	46
Starting Procedure	47
Flooded Engine	50
How to Stop the Engine	51
Shifting Gears	52
Braking	54
Riding Your ATV	56
Making Turns	56
Skidding or Sliding	58
Riding Up Hills	59
Riding Down Hills	63
Crossing or Turning on Hills or Slopes	64
Riding Over Obstacles	66
Riding Through Water	67
Parking	68