


# Controls & Features

## Headlight Switch



### LEFT HANDLEBAR



(1) headlight switch

(2) headlight dimmer switch

- ON
- OFF
- HI
- LO

The headlight switch (1) is used to turn the headlights and assist headlight ON ( ) or OFF ( ). To operate, turn the switch to ON ( ) or OFF ( ).

## Headlight Dimmer Switch



The headlight dimmer switch (2) is used to change between the high and low beams of the headlight. To operate, turn the switch to HI ( ) for high beam, LO ( ) for low beam.

The headlight dimmer switch will not change the assist headlight beam.