

# Quick Reference

---

|                         |   |
|-------------------------|---|
| Scheduled Maintenance   | Initial: 100 miles (150 km)<br>Regular: every 600 miles (1,000 km)  |
| Pre-ride Inspection     | Check the following items each time before you ride ( <a href="#">page 63</a> ): engine oil, radiator coolant, fuel, tires, drivetrain boots, guards, nuts & bolts, underbody & exhaust system, air cleaner housing drain tube, leaks, loose parts, cables, lights, throttle, brakes, reverse assist lever, switches, steering. |
| Fuel/Capacity           | unleaded gasoline, pump octane number 86 or higher<br><b>3.88 US gal (14.7 ℓ)</b><br>reserve:<br><b>1.29 US gal (4.9 ℓ)</b>   |
| Engine Oil              | API Service Classification SG or higher except oils labeled as energy conserving or resource conserving on the circular API service label, SAE 10W-30, JASO T 903 standard MA, Pro Honda GN4 4-stroke oil or equivalent   |
| Maximum Weight Capacity | <b>551 lb (250 kg)</b><br>rider, all cargo and accessories  |