


Indicators & Displays



When the fuel gauge show "E _ _ _ _ F" (4) and "LO FUEL" (5) blink 3 times alternately and fuel mark blinks, you should refuel as soon as possible.

(The fuel mark blinks except the fuel gauge display)

The amount of fuel reserve approximately:

1.29 US gal (4.9 l)

Fuel gauge failure:

If the "E _ _ _ _ _ F" (6) blinks, the fuel gauge function fails. See your dealer.

