


# Indicators & Displays

---

The indicators and displays on your ATV keep you informed, alert you to possible problems, and make your riding safer and more enjoyable. Refer to the indicators frequently. Their functions are described on the following pages.



- (1) neutral indicator
- (2) reverse indicator
- (3) differential lock indicator
- (4) PGM-FI indicator

- (5) high coolant temperature indicator
- (6) PS (Electric Power Steering) indicator (TRX500FM2 only)
- (7) multi-function display
- (8) mode select button